### ROYAL CONSUMER INFORMATION PRODUCTS INC.

#### ONTARIO & BC HARMONIZE SALES TAX

# Effective July 1, 2010

Programming Instructions for the following models:

582cx, 583cx.

- 1. Turn the programming key to the "PRG" position.
- 2. Enter"131" then press the "Void Key"
- 3. Enter "1" then the "Tax1" key, press "0" then press the NON TAX key, enter the tax rate (13000) for 13% then press "TAX2" key.
- 4. Enter "2" then the "TAX1" key, press "0" then press the NON TAX key, enter the tax rate( 5000) for 5% then press "TAX2" key.
- 5. To link the 13% to the desired department please apply the following steps.
- 6. Enter "00001" press (ST/W/Tax) press "0" then press the department you want taxable by 13%.
- 7. Enter "00002" press (ST/W/Tax) press "0" then press the department you want taxable by 5%.
- 8. Please turn the programming key back to the "REG.Position".

### ROYAL CONSUMER INFORMATION PRODUCTS INC.

## Progammation de base pour les models suivant:

582CX, 583CX

Insérez la clef de programmation (PRG) dans la serrure de contrôle et placez-la en position (PRG).

Programmer les décimales : Entre 2 et appuyer sur (-%/RA).

Programmer l'arrondis ment : Entrez 50 et appuyer sur (CHARGE).

Date: (ex Janvier 24,2010) Entrez (012410) et appuyer sur (#/ST/NS).

L'heure : style militaire, exemple, pour indiquer 19 :15 entrez 1915 et appuyer sur (QTY/Date).

Pour programmer les taxe :

Entre 131 et appuyer sur (Void).

Entrez 1 et appuyer sur (TAX1) entrez 5000 et appuyer sur (TAX2).

Entrez 2 et appuyer sur (TAX1) entrez 7500 et appuyer sur (TAX2).

Note: pour la province du Québec TAXE sur TAXE model 582cx entrez 211 et appuyer sur (VOID). Le model 583cx entrez 221 et appuyer sur (VOID).

Pour joindre les Taxe au département faite le suivant :

Pour les taxe de 5% et 7.5% ensemble, entrez 00005 et appuyer sur (ST/W/TAX) entrez 0 et appuyer sur le département que vous voulez taxable.

Pour la taxe de 5% seulement entrez 00001 et appuyez sur (ST/W/TAX) entrez 0 et appuyer sur le département que vous voulez taxable.

Tournez la clef (PRG) à la position (REG).